


H 10-4 L

LCD Wandhalterung
LCD Wall Mount



1 M4x30 (x4)

2 M5x30 (x4)

3 M6x30 (x4)

4 M8x40 (x4) M8x25 (x4)




5 12x6,5x13 (x4) 18x9x20 (x4) M6 (x8) M8 (x8)

6 Ø10x45 (x6) 6x62 (x6) M6 (x6)

7 5 mm

5 mm

M6x25 (x2)



MONTAGEANLEITUNG
ASSEMBLY INSTRUCTIONS

Montageanleitung
Instrucções de montagem
Montij Rehber
Montierungsanleitung
Návod pro montáž
Instrucciones de montaje
Asamussõlje
Asembly instructions
Oδηγία συναρμολόγησης
Montagehandleiding
Instrucciones de montaje
Montinginstruksjon
Instrucții de montaj
Montážní příručka
Montážna instrukcja
Pagadrijutis
Montarimo instrukcija
Monteringensvejledning
Montezes instrukcja
Instruzioni d'uso



H 10-4 L
LCD WANDHALTERUNG
LCD WALL MOUNT

WALL
TV MOUNT ACCESSORIES